

TT DIAL INDICATING SCREWDRIVER

TT TOURNEVIS DYNAMOMETRIQUE A CADRAN

TT DREHMOMENT-SCHRAUBEN-DREHER-MIT ANZEIGESKALA



DIAL INDICATOR DEL PAR DEL ATORNILLADOR

GIRAVITE DINAMOMETRICO A QUADRANTE

TT VISAR INDIKERANDE MOMENT SKUVMEJSEL

MOMENT SCHROEVEDRAAIER

TT 錶式指針型扭力起子



NORMAL USE

UTILISATION HABITUELLE

NORMALER GEBRAUCH


EMPLEO NORMAL

IMPIEGO NORMALE

NORMAL ANVANDNING

NORMAAL GEBRUIK

正 常 使 用



MEMORY MODE

MODE MEMOIRE

SPEICHER-FUNKTION

MODO MEMORIA






IMPIEGO CON

INDICATORE DI MASSIMA

MINNESFUNKTION

GEHEUGEN STAND







記 憶 模 式



GENERAL INSTRUCTIONS

INSTRUCTIONS GENERALES
ALLGEMEINE ANWEISUNGEN
INSTRUCCIONES GENERALES
ISTRUZIONI
ALLMANNA INSTRUKTIONER
ALGEMENE INSTRUCITIE

綜合概論



MHH ENGINEERING Co. Ltd.

Bramley, Guildford,
Surrey GU5 0AJ, England

 ** (0)1483 892772

 ** (0)1483 898555

WWW.Torqueleader.com