

TruTorque TTf



- Unlock • Déverrouiller la mollette
- Entsichern • Sbloccare • Desbloquear






- Adjust • Régler • Einstellen
- Regolare • Ajustar



- Lock • Verrouiller la molette • Sichern
- Bloccare • Bloquear

- Clockwise Torque Tightening
- Fonctionnement en sens horaire
- Drehrichtung im Uhrzeigersinn (Vorwärts)
- Funzionamento in Senso Orario
- Funcionamiento a derechas

- Anti-Clockwise Torque Tightening
- Fonctionnement en sens anti-horaire
- Drehrichtung im Gegenuhrzeigersinn (Rückwärts)
- Funzionamento in Senso Anti-Orario
- Funcionamiento a izquierdas



- Apply Torque • Appliquer le couple
- Drehmoment Anwendung • Applicare la coppia
- Aplicar el par de apriete